

## ADD-ON OPTIONS

For Battery Powered Machine Skates

Compatible with  
Model **EP5, EP15 and EP25**



Select changes to functionality or chose additional components. Some features may require additional lead time.



### Interchangeable or Independent Remotes

Each remote control is set to the same frequency by default. This allows the user to swap between components for backup. If this option is selected, two or more remotes are programmed to independent frequencies, allowing the simultaneous operation of multiple skates instead.

### Add-On Option: **EP-Multi**

Change to Independent Frequency



### Cable Remote (Disables Signal)

Connector Cable. Turns wireless remote into wired pendant-type remote control and disables wireless signal for security sensitive sites. Easy connect/disconnect.

### Add-On Option: **EP-Cable 45**

45-Foot Cable

### Add-On Option: **EP-Cable 195**

195-Foot Cable



### Bluetooth Disabled

Bluetooth permanently disabled at factory. Disables signal for security sensitive sites.

### Add-On Option: **EP-Blue**

Disable Bluetooth Functionality



### 110V Powerpack

Transformer with power cord. Powers machine skate via extension cord connected to 110V Outlet (or 220V). Requires 9 A under full load. Eliminates use of battery.

### Add-On Option: **EP-PPack**

Plug-In Power Pack



### Storage Box

Steel storage box. Allows charging of battery while stored.

### Add-On Option: **EP-Box**

Storage Box



### Additional / Replacement Battery

Additional / replacement battery.

### Add-On Option: **EP-Battery**

Extra Battery



**MADE IN GERMANY**

By **JUNG**



**5 Year Manufacturer's Warranty**

**1 year on all electrical components**

(damage due to overloading not covered)