

ADD-ON OPTIONS

For Battery Powered Machine Skates



Select changes to functionality or chose additional components. Some features may require additional lead time.



Lift Functionality

Lifting functionality for the powered skate. Lifting and lowering of the turntable is operated by an additional button on the remote control. Adding this feature, adds the box, housing the hydraulic mechanism to the back of the skate. This lifting features is intended for loads that require lift on ONE SIDE ONLY. **Factory installed option, cannot be added after-market.**

Add-On Option: EP5optL

For EP5

EP15optL

For EP15

Available on: EP 5 and 15



Cable Remote (Disables Signal)

Connector Cable. Turns wireless remote into wired pendant-type remote control and disables wireless signal for security sensitive sites. Easy connect/disconnect.

Add-On Option: EP-Cable 45

45-Foot Cable

Add-On Option: EP-Cable 195

195-Foot Cable

Available on: EP 15 and 25



110V Powerpack

Transformer with power cord. Powers machine skate via extension cord connected to 110V Outlet (or 220V). Requires 9 A under full load. Eliminates use of battery.

Add-On Option: EP-PPack

Plug-In Power Pack

Available on: EP 5, 15 and 25



Storage Box

Steel storage box. Allows charging of battery while stored.

Add-On Option: EP-Box

Storage Box

Available on: EP 5, 15 and 25



Additional / Replacement Battery

Additional / replacement battery.

Add-On Option: EP-Battery

Extra Battery

Available on: EP 5, 15 and 25