

**Tel: (800) 786-6112** Fax: (866) 332-3299

www.Toolwell.com

Email: info@toolwell.com

## **BÖRKEY ROLLER**

# **Guiding Caster Add-on Options**



#### Working load limit of guiding casters

Model size	Admissible Radial Force per Guide Roller (Tons)	Admissible Radial Force per Guide Roller (KN)
# 1, 2, 3, 3v	1	10
# 4, 5, 5L	10	100
# 5v, 6	15	150

Guiding side casters for use on tracks such as crane rails or steel beams for repeat journeys

- ▶ If parallelism of rails is uncertain, outfit rollers on one rail with guiding casters only, and use 4 casters per roller.
- ▶ If parallelism of rails is assured, rollers can be outfitted with just two casters on each roller on both rails.
- Maximum speed: 16ft/min (5 m/min)

#### **HOW TO ORDER:**

## 1. Choose Caster Configuration











Add-on Option:

Α


B

C

Ε

### 2. Choose Caster Offset

Provide distance X:



Distance from the center of the roller to the side of the guiding caster

