

Tel: (800) 786-6112

www.Toolwell.com Email: info@toolwell.com


Fax: (866) 332-3299

Skate: A16/B16

# WEIGHT DISTRIBUTION ON FLOOR

For machine skate models A16 (JLB 16S) and B16 (JFB 16S)

### **Wheel Footprint**




#### Wheel size

- ► length: 2.3" | 60mm • ► diameter: 3.5" | 90mm
- Wheel contact surface with floor
- ▶ width: 0.87" | 22mm • ► length: 2.4" | 61mm

## Footprint per wheel:

• **2.01 in<sup>2</sup>** | 13.4cm<sup>2</sup>

## **Skate Footprint** Skate Model **A16**



Footprint per skate: ▶ 32.16 in<sup>2</sup>


Skate Model **B16** 



Footprint per skate: ▶ 32.16 in<sup>2</sup>

### Footprint per ft<sup>2</sup>

Maximum footprint within any 1 ft2 area



1 ft<sup>2</sup> area

**Footprint** per ft<sup>2</sup>:

• > 16.08 in<sup>2</sup>

### **Variations in Footprint:**

With increasing weight, the elastic JUWAthan wheel material spreads out and increases the contact area with the floor. The enlarged footprint divides the weight over a larger area so that the pressure onto the floor is drastically reduced. The footprint above is measured at maximum load capacity. (1) The size of the actual footprint and in turn the actual psi may vary based on actual load weight, temperature, load bearing duration, etc.. Therefore the data provided is an estimate to be used as a general guideline only.

## Pressure per in<sup>2</sup> for concerns about indenting soft floor

Load weight (lbs) per skate Pressure (psi) = -Footprint (in<sup>2</sup>) per skate

Pressure per in<sup>2</sup> at maximum load capacity • ▶ 995 psi

Pressure per ft<sup>2</sup> for concerns about breaking through supported floor

Load weight (lbs) per skate x Footprint (in<sup>2</sup>) per ft<sup>2</sup> Pressure (psf) = Footprint (in²) per skate

Pressure per one ft<sup>2</sup> at maximum capacity > 16,000 psf