

Tel: (800) 786-6112

Fax: (866) 332-3299

www.Toolwell.com


Email: info@toolwell.com

Skate: **T6/B6** 

# WEIGHT DISTRIBUTION ON FLOOR

For tandem machine skate models T6 (JTLB 6K) and B6 (JFB 6K)

### Wheel Footprint



#### Wheel size

F • ▶ length: 3.3" | 85mm H • ▶ length: 1.6" | 42mm F&H • ▶ diameter: 3.3" | 85mm

#### Wheel contact surface with floor


F • ➤ width: 0.79" | 20mm
F • ➤ length: 3.35" | 85mm
H • ➤ width: 0.79" | 20mm
H • ➤ length: 1.67" | 40mm

# Footprint per wheel:

**F**• ► **2.65 in<sup>2</sup>** | 17.0cm<sup>2</sup> **H**• ► **1.32 in<sup>2</sup>** | 8.0cm<sup>2</sup>

### Skate Footprint


Skate Model



Footprint per skate: • > 21.2 in<sup>2</sup>

#### Footprint per ft<sup>2</sup>

Maximum footprint within any 1 ft<sup>2</sup> area



1 ft<sup>2</sup> area

Footprint per ft<sup>2</sup>:

• > 10.6 in<sup>2</sup>

#### **Variations in Footprint:**

With increasing weight, the elastic JUWAthan wheel material spreads out and increases the contact area with the floor. The enlarged footprint divides the weight over a larger area so that the pressure onto the floor is drastically reduced. The footprint above is measured at maximum load capacity. (1) The size of the actual footprint and in turn the actual psi may vary based on actual load weight, temperature, load bearing duration, etc.. Therefore the data provided is an estimate to be used as a general guideline only.

### Pressure per in<sup>2</sup> for concerns about indenting soft floor

Pressure (psi) = Load weight (lbs) per skate

Footprint (in²) per skate

Pressure per in<sup>2</sup> at maximum load capacity • ► 623 psi

# Pressure per ft<sup>2</sup> for concerns about breaking through supported floor

Pressure (psf) = Load weight (lbs) per skate x Footprint (in²) per ft²

Footprint (in²) per skate

Pressure per one ft² at maximum capacity • ► 6,600 psf